


# DIANA p-five

4,5mm (.177)

DIANA®



| NO. | ART-NO.       | DESCRIPTION            | QTY. |
|-----|---------------|------------------------|------|
| 1   | 03.04.02.0032 | FRONT SIGHT            | 1    |
| 2   | 04.01.01.0023 | BARREL 4.5             | 1    |
| 3   | 03.03.02.0163 | BREECH                 | 1    |
| 4   | 04.01.04.0137 | BARREL ADJUST WASHER   | 1    |
| 5   | 03.05.01.0120 | BARREL O RING          | 1    |
| 6   | 04.01.04.0138 | LOCK NUT               | 1    |
| 7   | 03.08.02.0254 | LATCH SPRING           | 1    |
| 8   | 03.03.03.0122 | LATCH                  | 1    |
| 9   | 03.01.01.0624 | H-L ADJUST SCREW       | 1    |
| 10  | 04.02.05.0128 | REAR SIGHT PIN 1,5X13  | 1    |
| 11  | 04.02.05.0015 | REAR SIGHT SCREW M3X6  | 2    |
| 12  | 03.04.03.0030 | REAR SIGHT BASE        | 1    |
| 13  | 03.04.03.0040 | REAR SIGHT             | 1    |
| 14  | 04.01.04.0131 | REAR SIGHT SCREW 2     | 2    |
| 15  | 03.04.03.0032 | REAR SIGHT BASE BOTTON | 1    |
| 16  | 03.08.02.0091 | REAR SIGHT BASE SPRING | 1    |
| 17  | 04.01.04.0073 | LOCK SCREW             | 1    |
| 18  | 10.03.0109    | LEVER                  | 1    |
| 19  | 04.01.04.0074 | LEVER PIN /REVIT       | 1    |
| 20  | 03.03.02.0141 | LOADING                | 2    |
| 21  | 04.01.04.0075 | LEVER PIN              | 1    |
| 22  | 03.03.02.0162 | AIR TUBE               | 1    |
| 23  | 03.05.03.0011 | PISTON O-RING          | 1    |
| 24  | 04.01.04.0076 | AIR TUBE PIN           | 1    |
| 25  | 10.03.0112    | PISTON                 | 1    |
| 26  | 04.01.04.0077 | HAMMER                 | 1    |

| NO. | ART-NO.       | DESCRIPTION       | QTY. |
|-----|---------------|-------------------|------|
| 27  | 03.08.02.0237 | PISTON SPRING     | 1    |
| 28  | 03.04.04.0341 | PISTON COVER      | 1    |
| 29  | 03.07.03.0136 | PIN               | 1    |
| 30  | 10.03.0114    | TRIGGER COVER     | 1    |
| 31  | 03.04.04.0310 | TRIGGER           | 1    |
| 32  | 03.08.03.0037 | SEAR SPRING       | 1    |
| 33  | 03.03.03.0123 | SEAR              | 1    |
| 34  | 04.01.04.0069 | M3 SCREW          | 1    |
| 35  | 03.08.03.0047 | TRIGGER SPRING    | 1    |
| 36  | 04.01.04.0070 | TRIGGER COVER PIN | 1    |
| 37  | 03.07.01.0391 | SCREW             | 2    |
| 38  | 03.04.01.0112 | GRIP PART-RIGHT   | 1    |
| 39  | 03.07.01.0260 | SCREW             | 4    |
| 40  | 03.07.01.0290 | SCREW             | 1    |
| 41  | 03.07.01.0329 | SCREW             | 2    |
| 42  | 03.04.01.0114 | GRIP PART-LEFT    | 1    |
| 43  | 04.02.05.0099 | PIN               | 2    |
| 44  | 04.01.04.0283 | 4 PIN             | 1    |
| 45  | 04.01.04.0072 | SCREW ST4.2×16    | 1    |